

spare part list: GT814/GT816 Econom CL for horse



GT367812 Spur gear



GT367200 Cutter head housing



GT367201 Rocker



GT367202 Vibratory spring blade



GT367203 Sleeve



GT367205 Regulating screw

spare part list: GT814/GT816 Econom CL for horse



GT367207 Cylinder screw




GT367802 Spacer peace, left



GT367803 Spacer peace, right



GT610405 Nut




GT610304 Rocker



GT610307 Spring link

spare part list: GT814/GT816 Econom CL for horse



TA008295 Screw shaft



TA010017 Screw M4x16



TA005091 Screw flat head M5x16



TA007765 Screw M3x8



GT801 Li-Io-batterie



GT803 Charger

spare part list: GT814/GT816 Econom CL for horse




GT800215 PT-Screw



GT800240 Ring o engine



GT800249 Switch



GT800895 engine compl- packed



GT800222 Spring clip




GT800819 Hard case

spare part list: GT814/GT816 Econom CL for horse



TA013898 Case sticker



GT800855 Circuit board



GT800841 Lower case



GT800842 Upper case



GT800844 Filter



GT604 Oil packed

spare part list: GT814/GT816 Econom CL for horse



TA009222 Screwdriver



TA012169 Cable UK



TA012170 Cable EU



TA012168 Cable USA
Canada Japan