

spare part list: GT6xx Bonum



GT640220 spur gear



GT647 cutter head packed cattle
GT657 cutter head packed horse



GT367201 rocker



GT367202 vibratory spring



GT640215 PT-screw 30x14



GT640225 regulating screw

spare part list: GT6xx Bonum



GT367207 cylinder screw




GT367802 spacer piece left



GT367803 spacer piece right



GT610405 nut




GT610304 rocker



GT610307 spring link

spare part list: GT6xx Bonum



TA008295 screw shaft



TA010017 screw M4x16



TA016336 Linsenschraube M5 x 16
Tx 25



GT641 Li-Io-batterie



GT643 (-G / -K / -A) charging station

spare part list: GT6xx Bonum



TA015304 instruction for use



TA015349 case sticker cattle



TA015350 case sticker horse




TA015351 case sticker horse




GT640819 hard case

spare part list: GT6xx Bonum




GT640895 engine packed



GT640896 PCB packed



GT640801 lower case



GT640802-RO upper case




GT640802-BL upper case



GT640802-OG-GEA upper case

spare part list: GT6xx Bonum



GT640249 switch



GT640248 button holder



TA009222 screwdriver



GT604 oil packed