

spare part list: GT444/GT446 Durati Horse



XT431 battery packed



GT200245 device with notches for switch



GT200248 device of push for switch



GT200249 button of contacts



GT640819 case
TA016201 sticker




XT430415 hinge complete (incl. 2 screw)

spare part list: GT444/GT446 Durati Horse



GT440802-NB upper case



GT440801-NB lower case



TA004637 thrust washer



GT800215 PT-screw 3 x 12




TA012140 PT-Torx screw 3x8



TA003820 locking washer
f/oscilatng arm


spare part list: GT444/GT446 Durati Horse

GT300305 calotte



XT430308 lever

XT430890 motor packed



GT200850 PCB



XT433 charging station
EU/UK/US/AUS



TA015445 instruction for use



GT604 oiler packed

spare part list: GT444/GT446 Durati Horse



TA015527 Torx screw
M3 x 8 TX